

INSTRUCTION SHEET

Part Number

611-463

Application: 2005–2013 Corvette

C6 Corvette Fuse Box Cover x/ Crossed Flags

Part Includes

- 1 Fuse Box Cover
- 1 Adhesive Promoter Pack
- 4 Velcro Attachment Cookies











Your new cover comes to you with a protective liner. Remove liner after installation is complete.

This great looking all stainless fuse box cover has been designed especially for the C6. It requires no tools to install or to gain access to your fuses. Just follow a few simple steps to change your plain black fuse box into a cool looking custom electrical center.

STEP 1. Thoroughly clean the top of the factory fuse box with alcohol to remove any and all road grime and dirt. Then swipe the area with the adhesive promoter provided.

STEP 2. You have been supplied with four Velcro attachment cookies. Simply peel the release liner from both sides of the cookies and place them at the four corners of the top of the factory fuse box cover. Then simply slide the new cover over the factory fuse box and press firmly over the Velcro cookies areas then remove protective liner.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order

to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner. SEE **ENCLOSED CARE SHEET!**

If any questions or problems occur during installation, please contact Mid America Motorworks at 1-800-500-1500.

Thank You and Enjoy Your Purchase!







Mamotorworks



@CorvettePassion



MidAmericaMotorworks





2900 North Third Street, Effingham, IL 62401 800.500.1500 · Worldwide: 217.540.4200 · FAX: 217.540.4800 www.mamotorworks.com · generalmail@mamotorworks.com OMid America Motorworks, Inc. All rights reserved.

.....