



Application: 2005-2013 Corvettes



Search: *Lighting, Exterior & Interior*
www.mamotorworks.com

C6 Reverse Light LED 80W Light Bulb Kit



Tools Needed



NOTES ABOUT C6 REVERSE LEDs: Raise the rear of the vehicle to gain access to the reverse light housings shown in the picture below. Please use jack stands! These are tucked pretty far back as you look above the lower rear fascia panel.

Step 1: Unlock the reverse light connector by turning it 1/4 turn upward or counter clockwise. Take note of the position of the socket when it comes out. You will need to line up the tabs on the socket with the slots in the housing and turn it 1/4 turn down or clockwise.



Step 2: Remove and unplug the factory bulb. It pulls straight out of its socket.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

Step 3: Since the factory wires aren't long enough to pull the socket completely out where its easy to change bulbs, you have to reach up there with both hands to change it. Be patient, it can be done. Have someone start the car and put it in reverse to test. If it doesn't light up, remove and turn it 180 degrees and plug it back in. Do both LEDs so you can be sure the brightness is the same on both sides. If one is dimmer than the other remove it, turn it 180 degrees and re install.



Step 4: Line up the tabs on the socket with the notches on the housing and once it is all the way in and seated, turn the socket clockwise to lock it in place. Repeat on other side and your done.
Now you have no excuse for backing into someone.....

