



Application: 2014-2019 Corvettes, Stingrays, Z06s, Grand Sports & ZR1s



Search: *Lighting, Exterior & Interior*
www.mamotorworks.com

C7 License Plate LEDs



Tools Needed



Step 1. Start at the left side of each housing. Use a screwdriver or similar tool to pry the lens down then slide the right side out.



Step 2. Hold the black connector then turn the housing counterclock-wise and remove the factory bulb. It may be hot!



Step 3. Turn on the running lights. Insert the led. If it doesn't light, turn it 180 degrees and re-insert it. Use the same procedure for both license plate bulbs.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.



Description (cont.)

Step 4. Insert the socket into the housing by aligning the tabs. Then turn the housing clockwise to lock it in place. Place the housing back into the opening clipping the right side in first then the left.

