



**Application:** 2014-2019 Corvettes

## C7 Hatch & License Plates LEDS



### Tools Needed



**Step 1.** Starting at the left side of the housing use a flat screw-driver or tool to pry the light housing down and out.



**Step 2.** Remove housing from rear fascia. Unlock the housing from the bulb socket by turning it 1/4 turn counter clockwise.



**Step 3.** Remove factory bulb. Be careful, it will be hot! Turn on the lights. Insert LED bulb. If it doesn't light, turn it 180 degrees and re-install. Reverse this procedure to re-install light.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)

©Mid America Motorworks, Inc. All rights reserved.



## Description (cont.)

**Step 4.** The rear hatch/trunk light housing can be easily removed by prying it out of the panel. Pull out at the red arrow.



**Step 5.** Using something non metallic (a pencil works best) push the factory bulb out of its contacts. It will be hot so don't let it burn your carpet or your fingers!



**Step 6.** Install the LED into the light housing. If it doesn't light, remove it turn it 180 degrees and re-install it. Also make sure the lights haven't timed out which they will do after about 15 minutes.





## Description (cont.)

**Step 7.** If you are still having trouble getting it to light make sure the factory contact (red arrow) is contacting the small LED wire (blue arrow). If they are not contacting each other you can move one or both of them to get contact. After all is working, re-install the housings and enjoy the new lights!

