



**Application:** 2014-2019 Corvettes



Search: *Lighting, Exterior & Interior*  
[www.mamotorworks.com](http://www.mamotorworks.com)

## C7 Rear Hatch/Trunk LED



### Tools Needed



**Step 1.** Start by prying the factory light housing out of the panel at the inside edge of the housing (red arrow).



**Step 2.** Using something non metallic (a pencil works best) push the factory bulb out of its contacts. It will be hot so don't let it burn your carpet or your fingers.



**Step 3.** Install the led into the light housing. If it doesn't light, remove it turn it 180 degrees and re-install it. Also make sure the lights haven't timed out which they will do after about 15 minutes.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

**2900 North Third Street, Effingham, IL 62401**  
**800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800**  
**[www.mamotorworks.com](http://www.mamotorworks.com) • [generalmail@mamotorworks.com](mailto:generalmail@mamotorworks.com)**  
©Mid America Motorworks, Inc. All rights reserved.



## Description (cont.)

**Step 4.** If you are still having trouble getting it to light make sure the factory contact (red arrow) is contacting the small LED wire (blue arrow). If they are not contacting each other you can move one or both of them to get contact. After all is working, re-install the housings and enjoy the new lights!

