



Installation Instructions

MC350

The NoviStretch™ MC350 mirror covers are designed specifically to fit all 1984-1996 C4 Corvettes and 2020-current C8 Corvettes.

▲ Note: The Corvette mirrors are asymmetrical. The driver side & passenger side mirror covers are **not interchangeable**.

Enclosed you will find:

- MC350 Mirror covers (left & right)

Tools Required:

- Plastic card (e.g. credit card, license, etc.)

STEP 1



Remove the covers from the packaging.

To identify the driver side cover from passenger side, place the covers with the slit opening facing you, the continuous seam along the top, and the bound/hemmed opening facing each other as shown above.

STEP 2



Holding the hemmed opening of the mirror cover, slide the cover over the mirror housing. Adjust the seam on the top to run along the top of the mirror housing.

▲ Note: It will take a reasonable amount of force to spread the opening as you push the covers over the housing.

STEP 3



Center the cover opening over the mirror glass. Push on one edge of the mirror glass to increase the gap between the glass and the housing.

STEP 4



Using a plastic card (credit card, license, etc), wedge the material into the gap opening.

STEP 5



After the material is behind part of the glass, create a gap on the other end by pushing the mirror glass. Continue to wedge the material behind the glass around the perimeter of the mirror.

STEP 5



Return mirror to a flat position. Repeat steps 2-5 to install the opposite side mirror cover.

▲ Safety Caution: Mirrors are repositioned during installation. Before driving the car, confirm the correct position of the mirrors from inside the car. If necessary, adjust using the mirror controls.

(Instructions continue on other side)

REMOVAL

The mirror covers can be removed by pulling the material from behind the mirror glass and sliding the cover off the housing.

REINSTALLATION

The slit opening expands during the initial installation process as it correctly sizes itself to your mirror, making reinstallation easy:



INITIAL SLIT SIZE

AFTER 1ST INSTALLATION

This stretching is normal and intentional.

Cleaning & Care Instructions

- The mirror covers can be cleaned during regular car washing (by hand)—just leave them on your car.
- If removed, covers can be hand-washed with mild detergent (such as car wash, laundry soap, etc.), rinsed, and allowed to air-dry.
- Do not use any solution containing bleach. Do not use a clothes dryer to dry the covers.
- Always ensure areas covered by the covers are clean and free of sand and grit before installing the covers.

Protecting Your Investment

NoviStretch® covers are constructed from synthetic stretch fabric that will not chafe or damage the painted surface and have been designed to perform in all weather and road conditions.

It is **important** that the painted surface be clean prior to installation of the cover. Over time and use, dirt or dust may work its way between the cover and the painted surface. Regular cleaning of both the cover and surface is **essential** to provide proper protection. Severe weather conditions or travel on off-road surfaces increase the recommended frequency for inspection and cleaning.

It is expected to see some cosmetic damage (small holes, thinning, fading or discoloration) to the covers over time & miles as it does its job. However, proper care will maximize product life.

NOVIGO DESIGNS™ TWELVE (12) MONTH LIMITED WARRANTY Novigo Designs, LLC warrants this product against “defects in material and workmanship” for a period of twelve (12) months from the original date of purchase by the original consumer purchaser. For full details and explanation of warranty coverage, requirements and policy, please go to the “Support” section of www.NoviStretch.com. Novigo Designs (and its authorized distributors) liability is limited to the materials and workmanship of the product. Novigo Designs is not responsible for damage caused by the product to the paint or finish of the vehicle. To avoid any possible damage and to get the maximum benefit from your Novigo Designs product, carefully follow the installation and care instructions provided. Novigo Designs, LLC.