



**Suggested Installation Instructions for:
361-093, 6 Meter Window Installation Tool**

1. With the weatherstrip on windshield start by inserting rope into outer groove of weatherstrip so that rope ends meet in the bottom center of windshield. (Note: Excess rope is inside the vehicle.)
2. Place glass into windshield frame from outside with rope ends hanging down inside vehicle.
3. Windshield should be held into position from the outside. Second person can now begin pulling the handle end of the rope into the vehicle while the person on the outside of vehicle applies even inward pressure on the windshield. (Note: Use soapy water in a spray bottle to help the weatherstrip slip into car body.)

Note: The same procedure can be used on the other fixed windows on your vehicle.