



Suggested Installation Instructions for: 602-135, 1968-1982 Power Window Replacement Spring

1. **INSTALL SAFETY BOLT AS SHOWN IN PHOTO** (Use 5/16 bolt washer & nut)
2. Now remove the motor from the regulator.
3. Remove the regulator from the door and secure in vise.
4. Holding the tension on the regulator arm, remove the bolt and release the spring. NOTE the position of the spring before removing. We suggest drawing a diagram of the spring for reference.
5. Remove the spring after the tension is released. Replace with the new spring in the same position. Refer to your diagram.
6. Swing the arm down until you are able to hook the spring end over the arm rivet.
7. Swing arm up until the hole in the gear matches the hole in the bracket. Install the safety bolt to hold the tension.
8. Re-install the regulator in the door.
9. Re-install the motor and the regulator. When the motor is secure, remove the safety bolt from the regulator.
10. Test the motor operation.

