


Suggested Installation Instructions for: 604-473, 604-476, LH Outside Mirror

Driver's Side Mirror Replacement for #604-473 & #604-476:

- 1. Remove allenhead screw (see diagram, Item #1). This releases existing mirror from mounting plate.
- Remove existing mirror, then mounting bracket screws (see diagram, Item #2)
 USE CAUTION-Existing screws can very easily be broken off during removal. If this occurs, the screws MUST
 be drilled out and threads tapped to complete the installation.
- 3. Remove mounting bracket and gasket.
- 4. To center new gasket, a "loose" installation of the mounting bracket and mirror is required. Place the new gasket on the door and loosely fasten the mounting bracket over the gasket. Fit the mirror onto the mounting bracket and center the gasket around the mirror.
- 5. Carefully hold the gasket in place, remove the mirror and tighten screws into the mounting bracket. Mount the mirror onto the bracket using new allenhead screw.



Mid America Motorworks, #1 Mid America Place, P.O. Box1368, Effingham, IL62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 • www.mamotorworks.com • mail@mamotorworks.com