

Application: all models

## **INSTRUCTION SHEET**

### Part Number



#### Part Includes

1 - Safety Switch Battery Disconnect

# Safety Switch Battery Disconnect



#### STEP 1.

Read CAUTION! before installing switch.

STEP 2.

Remove key from the ignition

STEP 3.

Keep disconnect arm in "open" position until all connections are complete.

#### FOR MODEL #20108, 20109, 20168, 20208:

#### STEP 4.

Remove battery's top cable from the battery's top negative (-) battery post. STEP 5.

Clean battery cable to the ost on the switch. For #20208, reattach battery cable to the post on the reciever side of the dissconnect.

#### FOR MODEL #20198:

STEP 4.

Remove Battery's cable from the nagative (-) battery post or terminal.

STEP 5.

Clean battery post on terminal for a good electrical contact.

STEP 6.

Find a suitable locaion and install the disconnect switch. MAKE SURE THAT YOUR HOOD OR OTHER METAL OBJECTS WILL NOT CONTACT THE SWITCH.

STEP 7.

Connect a cable from the "pivot side" pf the disconnect switch to chassisground. STEP 8.

Connect a cable from the "receiver side" of the disconnect to the negative (-) batery terminal.



2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....