



Application: 1984-1987 Corvette

Part Includes

1 - Component

Electric Relay Headlight Actuator Control



Tools Needed



Search: *Electrical System*
www.mamotorworks.com

The 1984-87 Corvettes have three relays that control the operation of the headlight doors. One isolation relay (#13006) and two for the headlight door actuators (#601-723[6760]). All three should be replaced at the same time.

The relays are located in the left front bumper area and are mounted on the inner wheel housing.

DIRECTIONS FOR SAFE AND PROPER APPLICATION

STEP 1.

To access the relays remove the two 7 mm screws holding the plastic cover over the relays.

STEP 2.

Remove the two 10 mm screws holding the bracket assembly to the inner wheel housing.


STEP 3.

To remove the relays, lift up the long metal plate lock that holds the relay to the bracket.

The relay will then slide off the bracket.

STEP 4.

Install the new relay and reassemble components by reversing Steps 1-3.



**LH FRONT OF ENGINE COMPARTMENT ON
WHEELHOUSE HEADLIGHT PANEL**



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401

800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800

www.mamotorworks.com • generalmail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.