

The First Convertible Top Cleaning and Protection System

HOW TO APPLY

RAGGTOPP Fabric/Vinyl Cleaner

- Wet Convertible Top thoroughly.
- Spray and apply evenly over entire roof and scrub lightly with recommended RAGGTOPP Deluxe soft brush.
- For very difficult soiled areas, spray and let stand for 15 to 20 minutes in the shade. Scrub lightly with RAGGTOPP Deluxe Soft Brush.
- Rinse thoroughly with water until no remaining soap foam is observed.

IMPORTANT: CONVERTIBLE TOP MUST BE THROUGHLY DRY BEFORE USING RAGGTOPP FABRIC PROTECTANT

RAGGTOPP Fabric Protectant FABRIC TOPS

- Start with a clean dry convertible top.
- Shake well before use and several times during spraying.
- Hold can upright and spray evenly 24-36 inches from material.
- Spray three *light* even coats of RAGGTOPP Protectant using gentle sweeping motion. DO NOT SATURATE.
- Allow to dry 10 minutes between coats in the sun. Artificial heat can be used to speed drying time. Allow 24 hours to dry.

USE A CLEAN COTTON TOWEL/RAG or MICRO FIBER TOWEL TO WIPE OFF ANY OVER SPRAY