



KIT CONTENTS:

- 4 – Tail Light Seals
- 8 – Phillips Head Screws
- 8 – Taillight Spacers (6 long, 2 short)
- 2 – Alcohol Wipes

TOOLS NEEDED:

- Torx-15 Screwdriver
- Phillips Head Screwdriver



- 1.** Remove screws with Torx-15 screwdriver.



- 2.** Remove & disconnect taillight.



- 3.** Clean taillight and bumper of dirt and loose debris.



- 4.** Clean taillight rim with alcohol wipe and allow to dry.



- 5.** Starting in the bottom center of the tail light, apply seal to black plastic so rounded edge hangs slightly over the red plastic lens. Trim the end as needed.





6. Insert Phillips head screws through tail light & place a spacer on the back. Short spacers are for the two outermost screws, long spacers are for 6 innermost screws.

7. Reinstall Taillight.

