




## KIT CONTENTS:

- Strut Assist Spring
- Spring Foot

## TOOLS NEEDED:

- Torx-30 Screwdriver



- 1.** Loosen 1 latch screw with Torx-30 Screwdriver



- 2.** Slide spring under latch screw and retighten

**NOTE:** For added strength, insert the nylon washer in the base of the spring and slide the latch screw through the center of the washer and retighten.



- 3.** Slide / twist foot onto spring.

- 4.** Lubricate struts and hinges.