



Application: 1997-2004 Corvette C5 (Including Z06)



Search: **Crossover Pipes**
www.mamotorworks.com

Part Includes

- 1 - X pipe
- 1- Hardware Kit

Crossover Pipe (X0-Pipe)



Tools Needed



PLEASE TAKE TIME TO READ AND UNDERSTAND THESE INSTALLATION INSTRUCTIONS.

MAM and CORSA recommend that installation of this system be performed by a qualified service center or professional muffler installer who has the necessary equipment, tools, and experiences personnel. However, if you decide to perform this install, the use of a hoist and an additional person will be required.

CAUTION: Never work on a hot exhaust system. Allow time for the vehicle to cool. Always wear eye protection when working under a vehicle.

Please confirm that all parts are present before beginning the factory exhaust system removal and CORSA exhaust system installation.

NOTE: Apply the anti-seize lubricant (supplied) to the threads ONLY of all the clamps and flange bolts. Failure to follow this procedure can cause the nuts to seize on clamps and potentially destroy threads. After applying anti-seize lubricant, be sure to thoroughly clean hands as lubricant will tarnish stainless steel. All clamps should be tightened using a properly calibrated Torque

Wrench. Using an air impact gun will damage the clamp and reduce its ability to effectively seal the joint. It may also cause the joint to separate thereby causing damage to your exhaust system and your vehicle.



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 N. Third Street, P.O. Box 1368, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • mail@mamotorworks.com

©Mid America Motorworks, Inc. All rights reserved.



Crossover Pipe (X0-Pipe)

CORSA X0-PIPE INSTALLATION:

STEP 1.

Locate the catalytic converter pipe bracket (See Fig. A) that mounts to the transmission housing. This will serve as the point from which to make your measurements to determine the required cutting points.

STEP 2.

Begin measuring by placing your tape measure on the front edge of the bracket (See Fig. A) and running the tape measure along the Driver's Side pipe towards the rear of the care. At 31 1/2", mark the pipe (See Fig. B).

STEP 3.

Repeat the process for the Passenger's Side pipe and marking the pipe at 30 inches (See Fig. C & D).

STEP 4.

Measure twice- cute once rule- Re-check steps and measurements.

STEP 5.

Using a chain cutter, cut the two staggered marks made on the intermediate pipe assembly. **IMPORTANT:** Be sure to follow the chain cutter instructions prior to making the final cuts. After the final cuts are made, your cuts

should look like those in Fig. E.

CAUTION: The cut edges are sharp, it would be a good idea to use sandpaper or a file to dull the edges.

STEP 6.

Next, remove the bolts from the intermediate pipe assembly to the over-the-axle pipe flanges (See Fig. F).

STEP 7.

Remove the two intermediate pipe hanger bracket bolts. Save these bolts, as they will be needed to install your CORSA Crossover Pipe (See Fig. G).

STEP 8.

Locate the two CORSA band clamps from the hardware kit and slip them over the catalytic converter pipes- do not tighten (See Fig. H). Note direction of clamps.

STEP 9.

Now slip the CORSA Crossover Pipe over the intermediate pipe assembly with the Crossover Pipe hanger bracket facing up. Driver and Passenger side inlets are labeled. For proper alignment, passenger side flange will be lower than driver's side.

STEP 10.

Reuse the center hanger bracket support bolts and lightly tighten.

STEP 11.

Locate the supplied flange bolts and gaskets in the hardware kit. Insert new gaskets at each flange and using supplied flange bolts, lightly tighten








FIG. A

FIG. B

FIG. C

FIG. D

FIG. E

FIG. F



Crossover Pipe (X0-Pipe)

(See Fig. I).

STEP 12.

Slip the CORSA band clamps over Crossover Pipe and lightly tighten.

STEP 13.

Before tightening, check to make sure everything is aligned and centered (See Fig. J). Then proceed to tighten the CORSA band clamps (See Fig. K), flange bolts (See Fig. L), and center hanger bracket (See Fig. M).

Torque Settings: Band clamps- 45 ft./lbs., Flange bolts- 40 ft./lbs., Center hanger bracket- 10-12 ft./lbs.

STEP 14.

Once installation is complete, start engine and check to ensure there are no leaks or rattles. It is **STRONGLY SUGGESTED** that all clamps be checked and tightened if necessary after road testing the vehicle and after system has cooled.

NOTE: During cold weather start-ups, you may experience an exhaust sound that is deeper and louder in tone than usual. This is temporary and will diminish to normal once your engine has reached its normal operating temperature.

NOTE: Immediately following the installation of your exhaust system, you may experience a trace of smoke after initial start-up. DO NOT be alarmed. The smoke is caused by the burning of a small amount of forming oil residue used in the manufacturing process.



FIG. G



FIG. H




FIG. I



FIG. J



FIG. K




FIG. L



FIG. M