

Application: 1997–2004 C5



Search: Exterior Lightening

Third Brake Light Pulser



DIRECTIONS FOR SAFE AND PROPER APPLICATION

The C5 Corvette Brake Light Pulser is a fully "Plug-N-Play" harness that plugs into your existing Center High Mount Brake Light. There are no wires to cut, and no adjustments to make.

STEP 1.

Using a T15 Torx driver, remove the 4 screws that hold the license plate bracket on the rear of the car. Pull the bracket down, remove the lamp sockets and set the bracket aside.

STEP 2.

Reach up to the third brake light and disconnect the 2-pin connector. You must pull the retaining tab back to release the lock as you pull the connector straight down. Gently pull the connector out the hole in the bumper.

STEP 3.

Connect this 2-pin connector to the mating connector on the BLP harness. Note the correct orientation and seat the connector until it snaps into place.

STEP 4.

Plug the remaining connector from the BLP harness into the third brake light. Again, note the correct orientation and seat the connector until it snaps into place.

With the engine off, stand behind the car and look at the center high

D AMERICA TORWORKS

Step 1.

Step 2.

Step 3.

Step 4.





R



@CorvettePassion

MidAmericaMotorworks

CorvettePassion

2900 North Third Street, Effingham, IL 62401 800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800 www.mamotorworks.com • generalmail@mamotorworks.com ©Mid America Motorworks, Inc. All rights reserved.

.....

INSTRUCTION SHEET

Part Number



Part Includes 1 – Third Brake Light Pulser



638-568

Third Brake Light Pulser

mount brake lamp. Ask someone to press the brake pedal. The lamp will pulse on and off for about a second, then it will stay on. Ask the person to release the brake pedal, and the lamp will turn off. If you press the pedal again within 15 seconds, the lamp will not pulse, it will just come on like normal. Release the pedal and wait 15 seconds or more. Press the pedal again, and the lamp will pulse then turn on.

Page 2