



Application: Corvette 1994-2000


Part Includes

1 - Mass Air Flow Housing

Mass Air Flow Housing



Tools Needed



Search: **Engine Components**
www.mamotorworks.com

STEP 1.

Disconnect and remove your stock MAF sensor and housing from your engine.

STEP 2.

Using a Torx screw socket, remove the 4 screws from the stock unit (figure 1). Set aside them aside for later use.

STEP 3.

Remove the stock housings from each side of the MAF sensor. Important: Do not touch or disturb the sensor wires inside the stock housing.

STEP 4.

Insert the rubber O-ring seals into the groove on each side of the replacement housing (figure 2).

STEP 5.

With the O-rings firmly in place, insert each of the air foils in the center groove of each housing (figure 3).

STEP 6.

Assemble all 3 pieces together with the factory MAF sensor in the middle (figure 3).

STEP 7.

Use the factory Torx screws to tighten all 3 pieces together (figure 4).

STEP 8.

Reinstall and connect the upgraded MAF sensor and housing to your engine. It is recommended to reset your vehicle's computer upon completion of the installation. This may be done by disconnecting your vehicle's battery, waiting 30 seconds, and then reconnecting it.



Figure 1



Figure 2




Figure 3



Figure 4



Mamotorworks



@CorvettePassion



MidAmericaMotorworks



CorvettePassion

2900 North Third Street, Effingham, IL 62401
800.500.1500 • Worldwide: 217.540.4200 • FAX: 217.540.4800
www.mamotorworks.com • generalmail@mamotorworks.com
©Mid America Motorworks, Inc. All rights reserved.